

Betriebsdaten:

Typical operation:

Exemple d'utilisation:

 $U_f . . . 6,3 \text{ V}$ $I_f . . . 0,2 \text{ A}$ $U_a . \text{ max } 200 \text{ V}$ $I_a . . \text{ max } 0,8 \text{ mA}$ $R_{fk} . \text{ max } 20 \text{ k}\Omega$ $U_{fk} \text{ max } 100 \text{ V}$ **Prüfdaten:**

Test operation:

Vérification:

 $U_f . . . 6,3 \text{ V}\sim$ $U_a . . . 10 \text{ V}\sim$ 

Röhre hat 2 Systeme.

Das 2. System ist in
Stellung 11 zu messen
2. System is measurable
in position 112. System est à essayer
en position 11

237

Patent-Röhrenprüfer Modell W19

MAX FUNKE, Adenau-Eifel 1. 55

EBC 11Triode + Duodiode
Karte 236 + Karte 237Unbrauchbar
mauvais / Bad

?

G u t
Good / Bon