

Urdox- und Eisen-Urdox-Widerstände

Bei Bestellung ist Angabe der Lager-Nr. unbedingt erforderlich

Osräm Type	Sockel-schaltung	Verwendung im Gerät	Sockel-Schaltbild	Lager-Nr.
U 920-6	normal	275 GW 110 V	1	—
U 920-6	spezial	192 GW 110-115 V	6	050723
U 920-6	spezial	265 GW 110 V	7	050735
U 1220-6	Edison-Mignon	259 GW 110-240 V	—	050323
U 1220-6	normal	340 GW 110-125 V	1	050323
U 2020-5	normal	275 GW 125 V	1	—
U 2020-5	spezial	147 GW 105-115 V	6	050704
U 2020-5	spezial	192 GW 115-125 V	6	050704
U 2020-5	spezial	265 GW 125 V	7	050736
EU VI	normal	151 GW 200-250 V	2	050436
EU VI	normal	198 GW 200-250 V	2	050436
EU VI	normal	275 GW 220-240 V	2	050436
EU VI	normal	147 GW 200-250 V	2	050436
EU VI	normal	192 GW 210-250 V	2	050436
EU VI	normal	265 GW 220-240 V	2	050436
EU VII	normal	151 GW 125-150 V	4	—
EU VII	normal	198 GW 125-150 V	4	—
EU IX	normal	340 GW 220-240 V	3	—
EU X	normal	151 GW 100-125 V	5	050437
EU X	normal	198 GW 110-125 V	5	050437
EU X	normal	275 GW 150 V	5	050437
EU XX	normal	147 GW 120-150 V	5	050703
EU XX	normal	192 GW 135-160 V	5	050703
EU XX	normal	340 GW 150 V	5	050703
EU XX	spezial	265 GW 150 V	8	050734

